

If you do not have the Mattoc 11mm Thin Wall socket you can also remove the compression rod by using a 4mm Allen wrench. Insert a 4mm Allen wrench into the air valve, pressing in the valve core. The wrench should insert into the valve about 7mm. Turn the compression rod **clockwise** until compression rod is disengaged from the casting threads.

