

Specialized's Instruction for set-up of E150 Double Crown Fork

To properly set up the E-150 double crown fork;

1. Remove and grease each crown bolt
2. Align the stanchions
3. Tighten the steerer tube nut, tight enough that the headset is not loose but not too tight or it will bind the steering
4. Tighten the steerer clamp nut
5. Tighten the lower crown bolts to 55 in-lbs, 6.1 N*m. (Alternate tightening each bolt)
6. Tighten the upper crown bolts to 75 in-lbs, 8.5 N*m

Reference your handle bar manual for the torque spec of your specific handlebar